

PDA Jacket

STYLISH PDA PROTECTION

INSTALLATION INSTRUCTIONS FOR THE iJACKET



The iJacket comes as a thin sheet of sticky colored vinyl between a sheet of plastic and a paper backing.



You peel away the paper backing.



Adhere it the back of your iPAQ after carefully aligning it.



Smooth it out around the iPAQ, being sure to push out any air bubbles.



Then carefully peel away the plastic sheet that covers the vinyl iJacket.



That's it!

Here's a front view...



...and a back view of your iPAQ.